

INSTRUCTION FOR USE

Dear customer,

Please read carefully this original manual before using your product for the first time. Behave according to its requirements and keep it for future use or for the future owner.

SUMMARY

- 1. Proper use.....
- 2. Safety instructions.....
- 3. Description of the equipment.....
- 4. Usage.....
- 5. Wearing the vest.....
- 6. Disassembly - Maintenance.....
- 7. Assembly after maintenance.....
- 8. In case of probleme.....
- 9. Technical specifications of the battery.....

1 Proper use

The Ekoï Refresh Vest is designed to reduce the increase of body temperature during home-trainer session. It has two membranes : the first inside is hydrophobic. It will extract your sweat. The second on the outside is water repellent and will prevent its evacuation Thus « imprisoned » your perspiration is cooled by four battery-operated fans.

It also results in a reduction of the temperature at the surface of the skin, a reduction of the feeling of fatigue, and an increase in comfort during the effort..

2 Safety instructions

- This vest is not intended to be used by unsupervised children or by persons at risk with reduced physical, sensory or cognitive abilities. It can still be used under supervision or if handling instructions have been given beforehand. The user must be aware of the dangers that may arise.
- This item is not a toy, keep out of reach of children.
- If you have problems feeling the heat or coolness, please refer to your doctor before any use of this product.
- When using it, check your body for skin reactions. The cold can cause burns if used for extended periods of time.
- Do not use this product in rainy weather or when it is quite humid. This product is not waterproof in any way.
- When not in use, leave the product in a dry storage.

- USE ONLY THE ACCESSORIES supplied with the product to recharge your batteries.
- Do NOT INSERT metallic or other object into the connectors or sockets, as this may damage the product.
- DO NOT make any modifications to the product.
- NEVER remove the protective film from the batteries. There is a risk of explosion if polymer batteries are handled improperly.

We accept no responsibility for any loss, damage, accident or litigation resulting from failure to observe the safety instructions when using the battery, fans or any of the accessories

Warning

Please observe the following rules for the correct use of the vest.

Please observe the following rules for proper use of the vest :

- Before charging the battery, make sure the poser is properly turned off.
- Do not disassemble or modify the battery.
- Do not place the battery in a fire .
- Do not puncture the battery.
- If you notice any deformation, leakage, corrosion or possible damage, please stop all use of the battery. Continued use of a damaged product or product part may result in injury.
- Do not immerse the unit in any type of liquid.
- Check the device regularly for defects.
- Do not dispose of with household waste , but in the battery containers provided for this purpose.



• Fans run at high speeds. Do not run your fingers through the fan blades Your finger could be trapped and cause injury. Vos doigts pourraient être coincés et provoquer une blessure. Also avoid contact of small objects with the fans.

3 Description of the equipment

- 1 vest
- 1 battery 5V, 5000mAh
- 1 battery charging cable

- 5 fans (including 1 spare) (fan + clamping ring with collar)
- 1 cable « 4 in 1 »
- 2 fan retainer washers



4 Usage

NOTE : The Ekoï Refresh Vest is delivered assembled.

For your first use, make sure that all parts are present.

1- Make sure the battery is fully charged.

2- Connect the cable to the USB port.

NOTE : the fans start automatically.

ON : To turn on the vest, press the switch once.

OFF : To stop the vest, press the switch for about 3 seconds

5 Wearing the vest

- The Ekoï Refresh vest is worn next to the skin
- The Ekoï Refresh vest can be worn indoor on home trainers.

During a session, it is **STRONGLY** recommended to hydrate regularly and in quantity.



6 Disassembly -Maintenance



Before cleaning, make sure the vest is turned off.

Remove all accessories (fans, cables, batterie, charger, collars) in this order :

1. Disconnect the battery and remove it from the pocket.
2. Disconnect the cable from each fan.
3. Unscrew the fans and remove them from the vest
4. Use the 2 zippers to remove the fan clamp rings if necessary.
5. Remove the « 4 in 1 » cable from the vest, then the 4 cables one by one through the eyelet.
6. When reassembling make sure that the collar of the clamping ring is in the right direction.

Maintenance instructions :

- Mashine washable at 30°.
- Before washing, turn the vest inside out (seams on the outside)
- No spinning
- No softener
- No tumble dryer
- No ironing

7 Remontage après entretien

7-1 Montage de la connectique

1 - Retourner l'intérieur de la poche arrière centrale pour découvrir l'œillet.

2 - Passer le câble « 4 en 1 » dans l'œillet



3 - R ressortir le câble batterie côté extérieur du gilet.

4 - Passer les câbles courts par les orifices prévus pour les ventilateurs arrière.



5 – Passer les câbles longs par les orifices prévus pour les ventilateurs avant.





ETAPES A REALISER POUR CHAQUE VENTILATEUR

- 1 - Dévisser la bague pour y insérer la rondelle. Puis laisser un léger espace entre la rondelle et la bague de serrage. Bien vérifier que la collerette soit du côté de la face du ventilateur, et bien positionner la rondelle.




- 2 - Placer le ventilateur sur le gilet dans l'orifice prévu à cet effet.



- 3 - Insérer le tissu du gilet entre le ventilateur (avec sa rondelle), et la collerette de la bague de serrage.
4 – Visser la bague de serrage.



5 - Brancher les câbles aux ventilateurs à la perpendiculaire, puis fermer en tournant la tête de branchement à 90°, à l'horizontal.



7-3 Mise en place de la batterie/branchement/ mise en marche

- 1 - Glisser la batterie dans la poche arrière, entrées USB vers le haut.
- 2 - Connecter le câble au port USB.



- 3 - Le gilet se met en marche automatiquement dès que vous branchez le câble au port USB.

8 En cas de problème...

- En cas de non fonctionnement des ventilateurs, assurez-vous que la batterie est bien chargée.
- La batterie possède un bouton ON/OFF sur le côté.
- Afin de faire fonctionner les ventilateurs, veuillez-vous assurer que la batterie est bien connectée à une alimentation de 2,1A minimum.
- Notre service après-vente se tient à votre disposition pour d'éventuelles questions ou en cas de problème.

9 Caractéristiques techniques de la batterie

Type de produit	Batteries externe Power Bank
Autonomie	2h
Capacité batterie	5000 mAh
Descriptif complémentaire	Output: USB A1: 5V 2.1A+ :
Descriptif complémentaire Dimensions produit	USB A2 : 5V 2.1A
	Input : Micro USB, 5V 2.1A .
	Temps de charge de la batterie : 3h pour passer de 0 a 100%
	H 0,15 cm x L 0,62 cm x P 0,85 cm

La durée de fonctionnement de la batterie dépend des circonstances d'utilisation.


Pour référence, la durée normale d'utilisation est de 2 heures.

La durée de la charge est d'environ de 1 à 3 heures selon le niveau de charge de la batterie.

A SAVOIR :

Il est nécessaire de charger complètement la batterie avant la mise en service.

Pensez à les recharger tous les 3 mois minimum, pour conserver la qualité et l'efficacité de la batterie.



FR

